



BT-SN3190

ITEM	PARTS NO	PARTS NAME
102	BTP11371-0374706-1	DEFLECTOR
104	BTP2040104-03010-0	HEX.SOC.HD.SCREW
105	BTP2040100-04030-0	BOLT ASSY
106	BTP11369-0375201-1	CAP
107	BTP11380-0374702-1	GASKET
108*	BTP11370-0370003-2	SEAL
109	BTP11360-0370001-2	COMPRESSION SPRING
111*	BTP2041108-05050-0	O - RING
112	BTP11368-0370003-2	HD.VALVE PISTON
113*	BTP2041108-07040-0	O - RING
114	BTP1136D-0374701-1	PRESS RING
115	BTP11302-0374713-1	CYLINDER CAP SEAL
116*	BTP11350-0370004-1	PISTON RING
117	BTP2041100-05050-0	O - RING
118*	BTP11204-0640014-1	DRIVER UNIT
119*	BTP11399-0370002-1	COLLAR
120	BTP11320-0370009-1	CYLINDER
121	BTP2041106-07020-0	O - RING
122	BTP11321-0370012-1	CYLINDER SPACER
123	BTP2041108-10010-0	O - RING
124	BTP11322-0370002-1	CYLINDER RING
125*	BTP11327-0370001-4	BUMPER
126	BTP1135S-0350001-1	GROMMET
127	BTP2040100-03090-2	BOLT ASSY
201	BTP2041104-02020-0	O - RING
202	BTP11374-0084701-1	PLUNGER CAP
203	BTP2041104-02030-0	O - RING
204	BTP2041100-01030-0	O - RING
205	BTP1133S-0250002-1	VALVE PLUNGER
206	BTP2041100-01070-0	O - RING
207	BTP11376-0254701-1	SPRING
208	BTP11375-0080002-1	PLUNGER
209	BTP2041102-01030-0	O - RING
210	BTP11373-0084701-1	TRIGGER VALVE HEAD
211	BTP2040400-05060-0	SPRING PIN
212	BTP2040400-05160-0	SPRING PIN
213	BTP2040400-05130-0	SPRING PIN

ITEM	PARTS NO	PARTS NAME
214	BTP11338-0374703-1	SAFETY GUIDE
215	BTP11376-0370001-1	SPRING
216	BTP11224-0764701-1	TRIGGER UNIT
217	BTP11318-0374701-1	TRIGGER PIVOT PIN
218	BTP1131D-0460001-1	URETHANE RETAINER
301	BTP11230-0375224-1	GUN BODY UNIT
302	BTP2040300-12010-0	C - RING
303	BTP1137N-0370001-1	FILTER
304	BTP11346-0371314-1	END CAP
305	BTP2041108-05040-0	O - RING
309	BTP1133D-0370002-1	HOOK
311	BTP1135V-0000009-1	AIR PLUG
314	BTP1132L-0350001-1	AIR PLUG CAP
316	BTP2041107-02030-0	O-RING
401	BTP2041101-07010-0	O - RING
402	BTP11382-0644705-1	NOSE PIECE
403	BTP11337-0644701-2	SAFETY SPRING
404	BTP2040302-27010-0	E - RING
405	BTP11332-0644704-2	SAFETY B
406	BTP11227-0644702-1	ADJUST ROD UNIT
407	BTP11393-0644702-2	ADJUST AXIE
408	BTP1138J-0644701-1	SAFETY SPRING A
409	BTP11331-0644705-1	SAFETY A
410	BTP1131C-0644701-1	RING
411*	BTP11339-0644702-1	PROTECTIVE CASING
412	BTP1131G-0374702-1	FIXED RING
413	BTP2040100-05010-2	BOLT ASSY
414	BTP11389-0644707-1	MAGAZINE A
415	BTP1136E-0644701-1	PROTECTING HOOD COVER
416	BTP11363-0644704-1	PUSHER
417	BTP1136F-0374701-1	SPRING
418	BTP11318-0084701-1	TRIGGER PIVOT PIN
419	BTP1136G-0834701-1	SQUARE UNITS
420	BTP2040101-02030-0	HEX.SOC.HD.BOLT
421	BTP11385-0374704-1	ROLL PIN
422	BTP11386-0370002-1	ROLLING ELEMENT
423*	BTP11372-0370001-1	SPRING
424	BTP2040102-02010-0	HALF ROUND HD.HEX.BOLT
425	BTP2040500-02010-0	LOCK NUT

ITEM	PARTS NO	PARTS NAME
426	BTP11396-0644708-1	STEEL CHANNEL
427	BTP11390-0644703-1	PROTECTING HOOD COVER
428	BTP2040102-02040-0	HALF ROUND HD.HEX.BOLT
429	BTP1130S-0644704-1	STOP NAIL PLATE
430	BTP11323-0644705-1	POSITIONING SHEET
431	BTP2040500-04010-0	LOCK NUT
432	BTP2040102-04010-0	HALF ROUND HD.HEX.BOLT
433	BTP2040202-04010-0	FLAT WASHER
434	BTP2040101-04090-0	HEX.SOC.HD.BOLT
435	BTP2040101-04020-2	HEX.SOC.HD.BOLT
436	BTP1137A-0644703-1	SAFETY COVER
437	BTP2040201-04010-0	FLAT WASHER
438	BTP2040501-04010-0	BOLT CAP
439	BTP2040201-04040-0	FLAT WASHER

The following parts are included in the BTPSNKIT1 parts kit:

107	113	116	119	123	401
111	115	117	121	124	

The following parts are included in the BTPSNKIT2 parts kit:

201	203	205	207	209	211	213
202	204	206	208	210	212	214